

FAQ ALLACCIAMENTI ELETTRICI

- *Come faccio a sapere dove si trova il punto di allaccio del mio stand?*

Il punto di allaccio è indicato nella pianta del vostro stand con il simbolo del "triangolo". La pianta è scaricabile dall'area riservata del portale Befair.

- *Che tipo di presa c'è nel mio stand?*

In tutti i padiglioni, ad esclusione dei pad. 28-29-30-MALL-37, l'allaccio avviene tramite cassette di derivazione con morsettiera situate nei cunicoli, bisognerà, pertanto, arrivare con il cavo spelato. Nei padiglioni 28-29-30-37 sono presenti, invece, dei pozzetti con prese da 32A. Le prese 32A sono disponibili per tutti gli stand. Nei padiglioni ci sono anche, in numero limitato, prese da 63A e 125A.

- *Il mio cavo deve avere delle caratteristiche particolari?*

Nel quartiere fieristico di Bologna viene richiesto un cavo della sezione minima di 6 mm. Si consiglia sempre di portare almeno 15/20 metri di cavo per essere sicuri di raggiungere il punto di allaccio.

- *Cosa devo fare per richiedere l'allaccio della corrente/attivazione del servizio?*

Dopo avere consegnato la documentazione dell'impianto elettrico presso l'ufficio antincendio, è necessario passare presso l'ufficio elettricisti (situato c/o centro servizi, 1 piano) e richiedere l'attivazione del servizio. Verrà richiesto il numero di quadri da allacciare e il totale dei kW impegnati, oltre al nome della ditta allestitrice dello stand.

- *Qual è la documentazione relativa all'impianto elettrico che devo inviare e a chi la devo inviare?*

La modulistica obbligatoria relativa all'impianto elettrico è costituita da:

- modulo B2 "Dichiarazione di conformità dell'impianto elettrico"
- Visura camerale della ditta che installa l'impianto

Questi documenti si possono caricare sul portale Befair o consegnare direttamente, in formato cartaceo, presso l'ufficio antincendio (c/o centro servizi, piano terra, Blocco B)

- *Se il mio quadro/cavo non va bene, cosa devo fare? E' possibile noleggiare materiale elettrico in fiera?*

Presso l'ufficio vendite (c/o centro servizi, 1 piano, Blocco D) è possibile noleggiare quadri elettrici (quadro + cavo). NON è possibile noleggiare SOLO cavi o SOLO quadri. All'interno della fiera NON viene venduto materiale elettrico.

- *Come si richiede l'aumento di potenza?*

Se i kW base compresi nella quota di partecipazione non sono sufficienti, è possibile richiedere un aumento di potenza, pari al TOTALE dei kW necessari, tramite il portale Befair. NB: bisogna selezionare UNA sola fascia di kW per ciascuno stand.

- *Cosa devo fare se ho più di un quadro elettrico?*

Ogni quadro elettrico presente sullo stand corrisponde ad un allaccio. L'allaccio del primo quadro è sempre incluso. Per ogni ulteriore quadro da allacciare è necessario fare richiesta di allaccio aggiuntivo tramite il portale Befair, selezionando la voce "Allacciamento aggiuntivo in padiglione".

- *Qual è la differenza tra impegno di potenza e allaccio aggiuntivo?*

L'impegno di potenza è il totale dei kW consumati dallo stand.
L'allaccio aggiuntivo si riferisce al servizio di allaccio di ogni ulteriore quadro elettrico, oltre al primo, da parte di uno dei tecnici della fiera.

- *Che cos'è la "verifica di rispondenza"?*

La verifica di rispondenza è il servizio di certificazione dei quadri elettrici installati da ditte (estere) non italiane.

- *Dove posso leggere il numero di presa da comunicare all'ufficio elettricisti al momento della richiesta di allacciamento (valido SOLO per i padiglioni 28/29/30/37)?*

Il numero di presa è scritto sulla presa stessa o riportato su un'etichetta attaccata al cavo all'interno del pozzetto. Il numero viene identificato con la dicitura "QP..." o "QMALL..."

- *Come funziona lo slaccio del mio quadro a fine manifestazione?*

Lo slaccio dei quadri dei padiglioni 28/29/30/37 può essere eseguito in autonomia, scollegando il proprio dal cavo dalla presa nel pozzetto. Per tutti gli altri padiglioni, passeranno automaticamente gli elettricisti incaricati da BolognaFiere a slacciare tutti i quadri. Non è necessario farne richiesta.

- *Se ho bisogno della corrente h24 cosa devo fare?*

Sarà cura dell'allestitore predisporre due linee/due interruttori sul quadro in modo tale che la sera si possano spegnere le luci e lasciare accesa la linea h24.

- *How do I know where my point of connection is?*

The point of connection is represented on your stand's layout with the "triangle" symbol. You can download the layout on your Befair personal area.

- *What kind of plug do I find on my stand?*

In every hall, except for hall 28-29-30-MALL-37, the connection is made through junction boxes with terminal board that are located under the tunnels. Therefore, you will have to bring a bare cable with you.

In hall 28-29-30-37 there are draw pits with 32A plugs which are available for every stand.

In the halls there are also 63A and 125A, but in a limited number.

- *Does my cable need special features?*

In BolognaFiere it is required to bring a cable with a minimum diameter of 6 mm. It is also recommended to always bring a 15/20 meters long-cable in order to be sure to reach the point of connection.

- *What do I have to do to request the electrical connection/activation of the service?*

After you have delivered the electrical system documentation to the safety service (services center, ground floor, wing B), or have paid the verification of compliance, you need to go to the electricians office (services center, first floor) and request the activation of the service. You will be asked to tell the fitting company, the number of switchboxes to connect and the total amount of kilowatts.

- *What is the electrical system documentation? Where do I need to send it? (ONLY FOR ITALIAN COMPANIES)*

The mandatory form of the electrical system is made of:

- B2 form "declaration of conformity of the electrical system";
- Certificate of incorporation of the fitting company.

These documents can be uploaded on the Befair portal or delivered, in the paper format, to the safety service (services center, ground floor, wing B).

- *What do I have to do if my switchbox/cable is not suitable?*

You can rent switchboxes, inclusive of cables, at the sales office (services center, first floor, wing D). It is NOT possible to rent switchboxes or cables separately. In BolognaFiere there is NOT a store where you can buy these materials.

- *How do I request a power increase?*

If the amount of kilowatts provided by default are not enough for your stand, it is possible to request, on the Befair portal, a power increase, which shall be equal to the TOTAL amount of kilowatts you need.

IMPORTANT: you can select ONLY one range of kilowatts for each stand.

- *What do I have to do if I have more than one switchbox?*

Every switchbox in your stand will match with a connection. The connection of the first switchbox is always included, while you have to request an extra connection for every additional switchbox, on the Befair portal, by selecting *"Extra Connection To The Electrical Network In The Hall"*.

- *What is the difference between power increase and extra connection?*

The power increase refers to the total amount of kilowatts that the stand will consume, while the extra connection refers to the connection of the switchbox that will be made by a BolognaFiere electrician.

- *What is the "Verification of compliance of the electrical system"?*

The verification of compliance of the electrical system is a switchbox certification service that is needed whether the switchbox is installed by a non-Italian company.

- *Where can I read the plug number (valid for hall 28/29/30/37 ONLY)?*

The plug number is either written on the plug itself or shown on the cable inside the draw pit by a label. The number can be identified by the word *"QP..."* or *"QMALL..."*.

- *How does the disconnection of my switchbox works when the event is over?*

If you are in hall 28-29-30-27 you can independently disconnect your switchbox by taking off the cable from the plug inside the draw pit. In the other halls you will need to wait for BolognaFiere electricians for your switchbox to be disconnected. It is not needed to make a request.

- *How can I do if I need h24 power?*

The stand builder will have to provide for two lines/switches on the box so that the lights can be turned off in the night, while the 24h line remains on.